

## SUNNY-NET PPPoE Setup Instructions for Elecom

First of all, connect to your Elecom wireless router either through Wi-Fi, or Ethernet. Next, open up a web browser and type in the following address: **192.168.2.1**

Username: admin

Password: admin

1. Select « *WAN & LAN* ».



2. Select « *WAN* ».



## SUNNY-NET PPPoE Setup Instructions for Elecom

3. Select « PPPoE ».

4. Input your Internet Username and Password, which Sunny-Net has provided.
5. Set the MTU to 1454
6. Select « Save », which is labeled '3'.
7. Finish by clicking « Save Now » which is the button on the left.