

SUNNY-NET TP-Link Setup Instructions

Step 1

Connect to your TP-Link router through Wifi/Ethernet and open a web browser, i.e. Google Chrome, Internet Explorer. Then follow the link below:
<http://tplinkwifi.net> or type in the following IP Address: 192.168.0.1
Username: admin Password: admin

Step 2

Configure WAN Connection Type

On the router's management page, click Network > WAN on the left of the web page:
Change the WAN Connection Type to PPPoE and under advanced.MTU=1454

Step 3

Enter your PPPoE username and password which is provided on the other PDF file.

The screenshot shows the WAN configuration interface. At the top, there is a green header with the word "WAN". Below it, the "WAN Connection Type" is set to "PPPoE/Russia PPPoE" in a dropdown menu, which is highlighted with a red box. To the right of this dropdown is a "Detect" button. Underneath, the "PPPoE Connection" section is also highlighted with a red box and contains three input fields: "User Name" with the text "username", "Password" with seven asterisks, and "Confirm Password" with seven asterisks. Below this, the "Secondary Connection" section has three radio buttons: "Disabled" (selected), "Dynamic IP", and "Static IP". The "Wan Connection Mode" section has four radio buttons: "Connect on Demand" (selected), "Connect Automatically", "Time-based Connecting", and "Connect Manually". Under "Connect on Demand", there is a "Max Idle Time" field set to "15" minutes. Under "Time-based Connecting", there is a "Period of Time" field set to "0 : 0 (HH:MM) to 23". At the bottom of the form, there are three buttons: "Connect", "Disconnected", and "Disconnected!". The "Save" button is highlighted with a red box. At the very bottom, there are two buttons: "Save" and "Advanced".

Step 4

Click Save to save your settings, then the router will connect to Internet after a while.